

USI-0002


Universal Safety Interface

Description

The USI-0002 communication module handles Ethernet and Serial communication with external devices, e.g. Experion™ PKS and Safety Builder. It is located in the Controller chassis (see section “CPCHAS-0001” on page 87 or “CPCHAS-0002” on page 116).

Figure 162 on page 271 shows the front view of the USI-0002 module.

Figure 162 Front view of the USI-0002 module



The main function of communication modules is handling the communication to and from external devices and other Safety Managers. The USI-0002 has four (4) independent communication channels. See Table 45 on page 272 for the relevant details.

Table 45 The communication channels of the USI-0002 module

| Channel | Description | Connector | Connects to | Communication cable |
|---------|---|----------------|--------------|---------------------|
| A | 10/100 Mb Ethernet ¹ Communication Channels | RJ45 | UCOM-HSE | CCI-HSE-01 |
| B | | | | |
| C | General purpose Serial Communication Channels | 10-pins AMP | DCOM-232/485 | CCI-UNI-01 |
| D | | | | |

1 The Ethernet interfaces are auto-ranging, they automatically select between 10 and 100 Mb.

Furthermore, the USI-0002 communication module acts as hardware firewall, protecting the safety functions within Safety Manager. It has:

- enhanced protective capability,
- more internal memory; this makes it suitable for running multiple demanding communication protocols in parallel.

The module consists of the following items:

- A Motorola 8260 communication processor.
- EEPROM to store specific module data, such as the two MAC-addresses and the hardware revision number.
- 8 Mbyte Flash memory to store the system and application program. The flash content is copied to SRAM at startup and is executed from there. The flash content can be updated without removing the USI-0002 from the Controller chassis.
- 8 Mbyte Local SRAM (with Error Detecting and Correcting logic) for system and application program and information.
- 256 kilobyte shared RAM for data exchange between the USI-0002 and the Control Processor.
- Two dual-speed fast ethernet transceivers
- Two general purpose serial communication controller channels.

LED Indicators

Table 46 on page 273 lists LEDs that are visible at the front side of the USI-0002 module.

Table 46 LED indicators of the USI-0002 module

| LED | Status | Description |
|-------------------|--------|--|
| Tx N ¹ | Green | Data is being transmitted on channel N [*] . |
| | Off | No data is being transmitted on channel N [*] . |
| Rx N [*] | Green | Data is being received on channel N [*] . |
| | Off | No data is being received on channel N [*] . |
| STATUS | Green | No hardware errors are detected in the module. |
| | Red | One or more hardware errors are detected in the module. |
| | Off | Power down or booting |

¹ N = 1, 2, 3 or 4.

Reset mechanism

The USI-0002 module resets hardware via the following mechanisms:

- Power-up or power-dip.
- If the Quad Processor Pack (key switch) goes in ‘STOP’ mode.
- If the Quad Processor Pack generates a COMmunication RESet.

The communication *channels* are reset (go offline) if:

- the module resets, or
- the dedicated watchdog times out.



Note:

A dedicated watchdog has been added to prevent a possible communication lock-out on the communication lines, if the processor on the USI-0002 gets a fatal error (e.g. program hang-up or loss of clock).

Hot swap

The USI-0002 module has ‘hot swap’ features.

This means that the module may be placed or removed in a running system. The application program will not be interrupted by these actions.

Additional specifications

The USI-0002 module has a galvanic isolation of:

- ≥ 2.5 kVdc between the 5 Vdc and the Ethernet signal.
- ≥ 1.5 kVdc between the Ethernet signal and the casing of the USI-0002.
- ≥ 1.5 kVdc between the 5 Vdc and the casing of the USI-0002.

If a memory error in the USI-0002 module is detected, the Quad Processor Pack will get an interrupt.

The USI-0002 module has a power-up self-test (diagnostics) phase for testing of the following components:

- Processor address- and data registers
- Local RAM
- Shared RAM
- Exception Handling
- Software integrity

Power-up self-tests are required to reduce the risk of defective hardware or corrupted software being used.

Technical data

The USI-0002 has the following specifications.

| | | |
|-----------------|------------------------|--|
| General | Type numbers: | FC-USI-0002 V1.0 |
| | Operating temperature: | $-5^{\circ}\text{C} \text{ — } +70^{\circ}\text{C}$ ($+23^{\circ}\text{F} \text{ — } +158^{\circ}\text{F}$) |
| | Storage temperature: | $-40^{\circ}\text{C} \text{ — } +85^{\circ}\text{C}$ ($-40^{\circ}\text{F} \text{ — } +185^{\circ}\text{F}$) |
| | Relative humidity: | 10 — 95% (non condensing) |
| | Approvals: | CE; TUV, UL, CSA, FM pending |
| Power | 5 V supply voltage: | 5 Vdc $\pm 5\%$ |
| | 5 V supply current: | max 1.2A |
| Physical | Dimensions: | $176 \times 35.2 \times 212$ mm (H \times W \times D) |
| | | $6.93 \times 1.4 \times 8.35$ in (H \times W \times D) |
| | Weight: | 0.7 kg |